



Note : This unit is pre wired for locks using power to lock.
 If your lock requires power to open move the blue wire
 from connector 10 to 9.

Please insure that this unit is fitted by a qualified electrician or similiar person. The mains power to the unit must have an isolator switch fitted close to the unit and have a 5A fuse installed.
 If you have any questions please go to www.wiztec.ie or phone support on =353-21-4316881.

8402 -002 Circuit Diagram
 June 2008
 Checked by : John Bourke